

JOBE VALVES AND ACCESSORIES

DISCOUNT CODE: B1

ROJO FLOAT VALVE



Code	Size mm	Size "
YJVRJV15	15mm	1/2"
YJVRJV20	20mm	3/4"
YJVRJV15HF	15mm	1/2"
YJVRJV20HF	20mm	3/4"

HI FLOW - LOW PRESSURE

DESCRIPTION

Rojo Float Valves are float operated valves for automatic filling of water storage vessels. The Rojo can be **mounted above or below water level**. It is a simple mechanically operated valve. The Rojo is a good choice where its **low flow** is sufficient and its compact non corrosive construction is beneficial.

ROJO PART FILL VALVE



Code	Size mm	Size "
YJVRJVP15	15mm	1/2"
YJVRJVP20	20mm	3/4"



AS1910
LIC 21606 SAI GLOBAL

DESCRIPTION

Rojo Part Fill valve intended for use in rain water harvesting tanks. The purpose of the float valve is to automatically maintain a low level of water in the tank during periods of no or low rainfall. This allows services fed by the tank to continue while leaving capacity in the tank for refilling by the next rain.

WATER LEVEL INDICATOR



Code	Size
YJVTANKWLI	ONE SIZE FITS ALL
YJVTANKLIP	1m Extension

DESCRIPTION

For use in water tanks to show water level at a glance

PROTECT-A-MOUNT



Code
YJVPMV

DESCRIPTION

Quickly and easily attaches to your trough or tank, to mount and protect your **Rojo** or **Topaz Valve**, without the use of tools

CONNECT BREAK FEED COUPLING



Code
YJVCNV20

DESCRIPTION

Quick coupling for use with Jobe valves equipped with **DETACH Valve Seal Access System**

For more details on the JOBE RANGE go to www.jobevalves.com

JOB VALVES

DISCOUNT CODE: B1

TOPAZ INDUSTRO VALVE



Code	Size	Size
YJVTPVI20D	20mm	¾"
YJVTPVI20DLT**	20mm	¾"
YJVTPVI25D	25mm	1"
YJVTPVI32D	32mm	1¼"

**** Detached Long Tail**

DESCRIPTION

Topaz Industro Float Valves are designed to maintain levels in applications requiring a valve with high mechanical strength and heat resistance, Industrial storage tanks and heated water cisterns. Some typical applications would be refilling cooling towers and storage tanks, High pressure cleaning and Car wash system as well as many light industrial, Air conditioning and Irrigation installations.

TOPAZ DIFFERENTIAL VALVE



Code	Size mm	Size "
YJVTPVD15DLT	15mm	½"
YJVTPVD20DLT	20mm	¾"
YJVTPVD25DLT	25mm	1"
YJVTPVD32DLT	32mm	1¼"

All Supplied with DETACH LONG TAIL

DESCRIPTION

Topaz Differential is a high flow Reservoir Valve for water storage tanks incorporating fully adjustable water level settings between on and off.

TOPAZ TROUGH VALVE



Code	Size mm	Size "
YJVTPV20D	20mm	¾"
YJVTPV25D	25mm	1"
YJVTPV32D	32mm	1¼"

DETACH BASE

YJVTPV15DLT	15mm	½"
YJVTPV20DLT	20mm	¾"
YJVTPV25DLT	25mm	1"
YJVTPV32DLT	32mm	1¼"

DETACH BASE LONG TAIL

DESCRIPTION

Topaz trough valves are float operated valves for use in automatic filling of water troughs, tanks, cisterns etc. The valve is configured for **above or below water mounting**. The float operates a small pilot valve which in turn operates the main diaphragm valve. Topaz trough valves are a good choice where their **high flow**, compact, robust, non corrosive construction and high level of adaptability are needed.

For more details on the JOBE RANGE go to www.jobevalves.com

JOBE VALVES

DISCOUNT CODE: B1

TOPAZ PART FILL VALVE



Code	Size mm	Size "
YJVTPVP15DLT	15mm	1/2"
YJVTPVP20DLT	20mm	3/4"
YJVTPVP25DLT	25mm	1"
YJVTPVP32DLT	32mm	1 1/4"

DESCRIPTION

Topaz Part Fill is a high flow valve intended for use in rain water harvesting tanks. The purpose of the float valve is to automatically maintain a low level of water in the tank during periods of no or low rainfall. This allows services fed by the tank to continue while leaving capacity in the tank for refilling by the next rain.

FREEZE PREVENTION DEVICE



Code
YJVFPV

DESCRIPTION

Freeze Prevention Device for Topaz Trough Valves

MEGA FLOW TROUGH VALVE



Code	Size mm	Size "	
YJVMFV20D	20mm	3/4"	Float Incl.
YJVMFV25D	25mm	1"	Float Incl.
YJVMFV32D	32mm	1 1/4"	Float Incl.

Tapered BSP DETACH

YJVMFV15DLT	15mm	1/2"	Float Incl.
YJVMFV20DLT	20mm	3/4"	Float Incl.
YJVMFV25DLT	25mm	1"	Float Incl.
YJVMFV32DLT	32mm	1 1/4"	Float Incl.

Long Parallel BSP Thread with Black nut & Washer DETACH LONG TAIL

DESCRIPTION

Mega flow trough valves are float operated valves for use in automatic filling of water troughs. The valve is configured for **underwater mounting only**. The float is connected to the valve with a nylon cord, this operates a pilot valve, when the water level drops, the pilot valve is opened drops, the pilot valve is opened and the main diaphragm valve is activated. Mega flow is a good choice where its **high flow**, compact, robust, non corrosive construction is beneficial

For more details on the JOBE RANGE go to www.jobevalves.com

JOBE VALVES

DISCOUNT CODE: B1

VORTEX BOTTOM FILL VALVE



Code	Size mm	Size "
YJVXVB32	32mm	1¼"
YJVXVB40	40mm	1½"
YJVXVB50	50mm	2"

DESCRIPTION

Vortex Bottom Fill valves are float operated valves for use in automatic filling of water troughs. The valve is configured for **underwater mounting only**. The float is connected to the valve with a nylon cord, this operates a pilot valve, when the water level drops, the pilot valve is opened and the main diaphragm valve is activated. Vortex is a good choice where its **high flow**, compact, robust, non corrosive construction is beneficial.

VORTEX DIFFERENTIAL VALVE



Code	Size mm	Size "
YJVXVD32	32mm	1¼"
YJVXVD40	40mm	1½"
YJVXVD50	50mm	2"

DESCRIPTION

Vortex Differential is a high flow Reservoir Valve for water storage tanks incorporating fully adjustable water level settings between on and off.

VORTEX PART FILL VALVE



Code	Size mm	Size "
YJVXVP32	32mm	1¼"
YJVXVP40	40mm	1½"
YJVXVP50	50mm	2"

DESCRIPTION

Vortex Part Fill is a high flow valve intended for use in rain water harvesting tanks. The purpose of the float valve is to automatically maintain a low level of water in the tank during periods of no or low rainfall. This allows services fed by the tank to continue while leaving capacity in the tank for refilling by the next rain.

VORTEX FLOAT VALVE



Code	Size mm	Size "
YJVXV32	32mm	1¼"
YJVXV40	40mm	1½"
YJVXV50	50mm	2"

STANDARD VALVE

DESCRIPTION

Vortex Float Valves are float operated valves for use in automatic filling water tanks, troughs, cisterns etc. The valve is configured for **above water mounting**. The float operates a small pilot valve which in turn operates the main diaphragm valve. Vortex float valves are a good choice where maximum **flow**, compact, robust, non corrosive construction and variable float levels are required.

For more details on the JOBE RANGE go to www.jobevalves.com

JOBE VALVE SPARE PARTS

DISCOUNT CODE: B1

ROJO, MEGAFLOW, TOPAZ & VORTEX

Code	Description
YJVRJP3A	Rojo Inner Cartridge Assembly
YJVRJP3B	Rojo Inner Cartridge Assembly (high flow - low pressue)
YJVRJPP3	Rojo Partfill Inner Cartridge Assembly
YJVMFP3	Megaflow Diaphragm Assembly
YJVTPP3	Topaz Diaphragm Assembly
YJVTPPI3	Topaz Industro Diaphragm Assembly
YJVVXP3	Vortex Diaphragm Assembly

